

Centurion II Power System

DC Power System

Installation / Operation Manual

Model:
C2RS (-48 VDC and +24 VDC)



M-C2RS
As of 070914



Newport Beach, CA USA

Powering the Network

www.newmartelecom.com ■ 800-854-3906

TABLE OF CONTENTS

Section	Description	Page
1	Receiving Instructions.....	2
2	Scope	2
3	System Overview	3
4	Installation.....	3
4.1	Unpacking & Installing in Frame.....	3
4.2	AC Cabling	4
4.2.1	Upstream Over-current Protection	5
4.3	DC Cabling	6
4.3.1	Terminal Block Labeling.....	6
4.4	Alarm/Ancillary Cabling.....	8
5	LVD Operation	10
6	Commissioning	11
7	Appendix 1 – Newmar Essential System Set – Up Parameters.....	17
8	Appendix 2 – Maintenance.....	19
9	Appendix 3 – AC Input Transient Protection	20
10	Appendix 4 – Rectifier Input Fuse Curves	22
11	Appendix 5 – Installation of AC Input Cover.....	23
12	Appendix 6 – Troubleshooting	24
13	Appendix 7 – Field Replacement of Load Circuit Breakers	25
14	Appendix 8 – System Wiring Diagrams	26

Installation CD

You may have received a CD with your Centurion II Power System. This contains the user manuals relevant to the System you have purchased, plus the SM3x Configuration Software. This software enables direct communication from your computer to the SM3x via the USB port.

Note: You will require Administrator rights on your computer to install this software.

If this is the first time you have used the SM3x Configuration Software, then the installation process will guide you through the installation of:

- the USB drivers,
- the Microsoft .Net Framework
- the SM3x Configuration Software itself

Upon inserting the CD, open the file directory. In the root directory there is a file called Setup_sm3xconf_4.2.exe. Double click on this and you will be guided through the installation process. Normally, you should only be required to click “next” on all prompts.

The number “...4.2” denotes the release issue of the Configuration Software (the file you receive may be 4.3, 4.4 or greater). If you have an earlier version installed than the number denoted there, then you can automatically update your existing software by double-clicking on this .exe file (it will not re-install your USB drivers or the .Net Framework).

The first time you connect your computer to a SM3x via the USB, Windows will “find new hardware”. Proceed to install the drivers “automatically”. If, during this process, you get a message from Windows stating that the driver is unsigned, it is not a problem. You must continue with the driver installation.

1 RECEIVING INSTRUCTIONS

CAUTION:



For your protection, the following information and the product manual should be read and thoroughly understood before unpacking, installing and using the equipment.

We present all equipment to the delivering carrier securely packed and in perfect condition. Upon acceptance of the package from us, the delivering carrier assumes responsibility for its safe arrival to you. Once you receive the equipment, it is your responsibility to document any damage the carrier may have inflicted, and to file your claim promptly and accurately.

Package Inspection

- Examine the shipping crate or carton for any visible damage: punctures, dents and any other signs of possible internal damage.
- Describe any damage or shortage on the receiving documents and have the carrier sign their full name.

Equipment Inspection

- Within fifteen days, open crate or carton and inspect the contents for damages. While unpacking, be careful not to discard any equipment, parts or manuals. If any damage is detected, call the delivering carrier to determine the appropriate action. They may require an inspection.
Save all the shipping materials for the inspector to see!
- After the inspection has been made and you have found damage, call us. We will determine if the equipment should be returned to our plant for repair or if some other method would be more expeditious. If it is determined that the equipment should be returned to us, ask the delivering carrier to send the packages back at the delivering carrier's expense.
- If repair is necessary, we will invoice you for the repair so that you may submit the bill to the delivering carrier with your claim forms.
- It is your responsibility to file a claim with the delivering carrier. Failure to properly file a claim for shipping damages may void warranty service for any physical damages later reported for repair.

Handling

Handle the equipment with care. Do not drop or lean on front panel or connectors. Keep away from moisture.

Identification Labels

Model numbers are clearly marked on all equipment. Please refer to these numbers in all correspondence with Newmar.3

2 SCOPE

This manual covers essential information for the installation and commissioning of the Centurion II DC Power System

System set-up for the rectifiers, alarms etc., are provided in separate manuals for the SM36 (C2C-36) supervisory module and rectifiers.

All installation and maintenance must be carried out by suitably qualified personnel.

Note: The Centurion II System is available with Positive Earth (-48Vdc, -60Vdc) or Negative Earth (+24Vdc). The installation manual covers both Positive and Negative Earth systems. The standard system is assumed to be a Positive Earth system. Where parameters and settings differ between systems, the Negative Earth system parameters are specified within parenthesis i.e. ().

3 SYSTEM OVERVIEW

The Centurion II DC Power System has a maximum power output of 6.0kW (+24V rated to 3.0kW @ 24V, 3.3kW @ 27V), producing a maximum current output of 125A/-48V (125A/+27V).

The system is intended to be a complete power system in a box, so no connections need to be made internally. All the AC, DC (Load and Battery) connections are made at the rear of the unit. Alarm connections are accessible from the front by pulling the Supervisory Module forward.

The system is designed to be extremely simple to install and set up.

The following is a summary of the system:

- Overall size is 483mm wide (19" standard mounting) x 88.9mm (3.5") high (2U) x 350mm (13.78") deep
- Up to 3 x 37 amp (-48V or +24V) C2R-2000 or C2RX-2048 rectifiers (may be packaged separately) or 3 x 18 amp (-48V) C2R-1000 rectifiers
- SM36 supervisory module (fully integrated in the system)
- Battery Low Voltage Disconnect fitted as standard (125A rating).
- 2x 100A Battery Circuit Breaker, these may be specified as different values at time of order.
- 8x 10A, 4x 20A, 4x 30A Load Circuit Breakers, these may be specified as different values (from 2A to 30A) at time of order.
- System weight is approximately 8.4kg (18.5 lbs.) without rectifiers, and 13.2kg (29 lbs.) with three rectifiers fitted.
- Three sets of single phase input terminals: A-L1, B-L1, C-L1 & A-L2, B-L2, C-L2 plus Earth are provided to allow two input wiring options: three low current single phase 220 VAC inputs. **Note: Two 3 position terminal block links/jumpers are provided (in manual bag) for single high current AC source wiring. See drawing #15646-0 located in manual bag for more information on AC wiring options.**

Note: This system is supplied with the AC and DC earths connected unless chassis DC isolation is specified when ordering. The standard -48 VDC system output has the DC Common in the positive side of the circuit (+ve earth system). On +24 VDC systems, the DC Common has the negative side of the circuit (-ve earth system) connected to system chassis/earth. The earth link can be removed from the system to isolate earths. Please see the relevant section.

4 INSTALLATION

4.1 Unpacking & Installing in Frame

Upon unpacking, check that the unit is not damaged, and that you have the required number of rectifiers.

The unit flush mounts into a standard 19" mounting frame. The mounting screws should be #12-24; however #10-32 may be used with washers. Be sure to mount the unit in the 19" frame squarely if #10-32 screws are used.

Please note the complete system weight is 13.2kg. (29 lbs.). Ensure the 19" mounting rails are able to withstand mounting of the system.

4.2 AC Cabling

The AC terminals are clearly marked at the rear of the system as shown in Fig 1.0 & 1.1. The terminals can accept up to 8 AWG/10mm² cables.

Once cables are connected, ensure cable connector clear cover is fitted and secured (not shown). Refer to appendix 5 for cover removal (page 23)

The AC earth terminal earths the System chassis. The AC earth is also internally bonded to the System chassis by earth stud as shown in Fig 1.1.

DC Common (+ve) is connected to the AC earth as shown in Fig 1.1, but can be removed if output is required to be isolated.

Note: Refer Appendix 3 for AC Input Transient Protection

CAUTION: For 3 phase operation remove the Single Phase link fitted between the phases.





Fig.1.0 AC Input Terminals



AC Input Terminals

Note: See Appendix 5 for information regarding installation of the AC input cover




Fig.1.1 AC – DC Earth Link

4.2.1 Upstream Over-current Protection

There are two considerations to take into account when selecting an appropriate fuse/circuit breaker.

- The upstream protection should protect the downstream cable from overload situations.
- Discrimination should be maintained with the downstream device fuses.

(i) Cable Rating

The maximum current drawn by the DC power system is 12.5A per 2kW rectifier (6.2A for 24V system and 48 VDC/1 kW rectifier modules), or 37.3A (18.7A for 24V system and 48 VDC/1 kW rectifier modules) per fully populated rectifier shelf at a minimum input voltage of 175V AC and full output power. The upstream protection device must be able to supply this load under all conditions without tripping. Therefore, typically at least 20% headroom is allowed for the protection device, making its minimum rating 15A/per 2kW rectifier (7.5A) or 44.8A (22.5A) for fully populated rectifier shelf.

Note: The current carrying capacity of cables is dependent on the type of cable used. Please check with your local supplier and local regulations for appropriate sizing.

(ii) Discrimination

Discrimination ensures that the upstream circuit breaker or fuse does not blow if a rectifier input fails (short circuit). Therefore it is important to ensure the upstream protection discriminates with the internal fuse of the rectifier. The fuse used in the RM2048/24, C2R-2000, and C2RX-2048 rectifiers is a slow-blow 15A fuse. The tripping curve for this is shown in Appendix 4 at the rear of this manual.

A minimum circuit breaker to use for this system is a 20A, D-curve (note, a 20A C-curve breaker will **not** discriminate with the rectifier fuse). Therefore, when used with the 2.5mm² cable supplied, a 20A, D-curve breaker should be used.

Alternatively, a 32A C-curve breaker, or greater, can be used. However, AC cable provided may have to be replaced for a larger cable¹.

If a fuse is used upstream, then any BS88 or NH g style fuse, of 20A or greater rating will discriminate.

4.3 DC Cabling

CAUTION: Use extreme care when fitting batteries & their connections. Remove all jewelry and rings from oneself prior to commencing the installation. Always use insulated tools when fitting batteries and take extreme care not to short terminals when working on them.



4.3.1 Terminal Block Labeling

Note: Your Centurion II Load & Battery Terminal Blocks maybe labeled differently than shown in photos on the following page. Some Centurion II shelves' terminal blocks are identified by Numbers which are the **Live or Hot** terminals and the words **Batt. Common** or **Load Common** which are the **Return** or **Ground** terminals – see polarity table below.

System Voltage	"Numbered" (AKA: Live or Hot)	'Common' (AKA: Return or Ground)
-48 VDC	-	+
+24 VDC	+	-

¹ NOTE: A larger breaker may be used even though in theory it may appear that the 2.5mm² wire is not fully protected. In fact it is protected on two accounts. Firstly it is protected by the rectifier input fuse (which is only a short distance away). Secondly, the rectifiers are power-limited on their input. Therefore, they can never be overloaded. As a result, the wire can never be over-loaded by the rectifier – it can only see fault current. As a result, depending on local authorities, only fault current protection may be catered for by the upstream protective device.




Fig. 2 Battery & DC Output Terminals (+ve Earth System, -48V or -60V)




Fig 2.1 Battery & DC Output Terminals (-ve Earth System, +24V)

All live DC and Common connections are made to the connectors at the rear of the unit as shown in Fig 2 and Fig 2.1.

For 1-8 load breakers 8Awg/10mm² terminals are used whereas for 9-16 load breakers, 10 Awg/6mm² terminals as shown in Fig 2 and Fig 2.1.

The battery terminals shown can accept cables up to 2 Awg/35mm².

The internal battery cabling goes directly to the circuit breaker, then via a Low Voltage Disconnect relay and current shunt to the internal live bus. This can be seen on the wiring diagram at the rear of this manual & in Fig 5.

Ensure cables are strain relieved by utilizing the cable tie slots provided as shown in Fig 2.

4.4 Alarm/Ancillary Cabling

Alarm and communication cables terminate directly into the terminals of the Supervisory Module. These terminals are accessible by pulling the monitor forward to expose connections as shown in Fig 3, Fig 3.1, Fig 3.2 & Fig 3.2a.



Fig. 3 (left): For removal, unlock SM31/32 by lifting green locking tab.

Fig. 3.1 (right): For SM35/36 removal, pull monitor forward to release the ball catch

When routing the cables, ensure they are kept away from the AC and DC power cables when possible.

For SM31/32 relay states labelled Normally Open or Normally Closed are for their de-energized state.




Fig. 3.2 SM31/32 Monitor Cabling




Fig. 3.2a SM35/36 Monitor Cabling

For SM35/36 Relays 1- 6 can be used for normally open or normally closed states by jumper selection. The relay states labelled NO or NC is for their de-energized state.

If an alarm is programmed for the relay to be normally energized (as may be required in the case of a low voltage alarm where loss of power will put the alarm into its active state), then be sure to connect the remote wiring appropriately.

For full monitor functionality and operation information, refer to the appropriate monitor manual.

Temperature Sensors

Uncoil the battery temperature sensor tie wrapped to rear of shelf and place in the middle of the middle battery string. If the lead is not long enough, ordinary 2-core copper (approx. 18 AWG/0.75mm²) wire can be used as an extension. The purpose of the battery temperature sensor is to monitor the ambient temperature of the batteries over long periods of time and adjust the rectifier output (float) voltage accordingly. As a result, it is not necessary to have the temperature sensor touching the batteries. If the Battery Temperature Sensor is removed a “battery temp fault” alarm is generated.

The “Ambient” temperature sensor (optional) can be used to monitor the temperature in another location if required.

Connecting via Computer

For remote communications and direct computer connection to the Compact System, refer to the SM36 Manual. These connections can be made via the mini-USB port on the front panel of the monitor (computer connection to the SM36, USB cable included) and the Ethernet port (SM36 web-based communications only). The Ethernet port has been extended to the rears of the shelf via a patch cord and RJ45 coupler for installer convenience.

When a laptop/pc is connected for the first time to the SM36, you the USB drivers will have to be installed on the connected computer. See the SM36 manual for details.

Help files can be accessed for a field by left clicking inside the field and pressing the F1 key on the keyboard. Example shown in Fig. 4




Fig. 4

Alarm Mapping to Volts-free Relays

The SM36 has three voltage-free alarm relay outputs as standard

Note that on all systems, Relay 1 is pre-configured as the “Monitor Fail” alarm. This alarm activates if the monitor has a hardware fault or if software becomes corrupted.

All other relays can be mapped to different alarm conditions. The SM36 Manual details how these may be changed. On the standard Centurion II Systems alarms are preconfigured as follows:

Relay 2: Summary Non-urgent alarm

Relay 3: Summary Urgent alarm

Relay 4, 5, & 6: User configurable

As mentioned, if these mappings are not appropriate, they can be changed in the field to suit customer requirements.

General Purpose Digital Inputs (GPIP) for external alarm contacts.

Circuit Breaker Fail Monitoring

Load circuit breakers are monitored electronically via a diode to a digital input on the SM36. The digital input will trigger an alarm when it is pulled to the system Common (positive) rail. This means that to operate, the load must be connected. In this way, false alarms are avoided when no load is connected and the load circuit breaker is in the “off” position.

Note: This means that a residual voltage will be measured at the load terminal even when the circuit breaker is turned off. This is high impedance and does not present a hazard to the user, this is normal.

The battery circuit breakers however, use auxiliary contacts to detect tripping or whether they are turned off. This is because when a battery breaker is tripped, there may be very little voltage difference, making electronic fail detection problematic. Hence, if only one battery is connected, both breakers must be “on” to clear the Battery Breaker Fail alarm.

5 LVD OPERATION

This system is configured with one Low Voltage Disconnect contactor, in the battery side of the circuit as shown below & in the Wiring Schematic at rear of this manual.

The SM36 Supervisory Monitor unit is powered from both the rectifier side of the battery LVD contactor and battery source. Therefore when the low voltage threshold of Battery LVD is reached, the LVD disconnects the battery and the SM36 will lose voltage sense (as voltage sense is measuring rectifier bus voltage) but still maintains operation for system monitoring.

Newmar • PO Box 1306, Newport Beach, CA 92663

• Phone: 714-751-0488 • E-mail: techservice@newmarpower.com

The Battery LVD contactor will not re-engage until the rectifier power is restored (i.e., until the DC bus voltage is restored).

LVD adjustments/settings are all made from the SM36. See the SM36 manual for details.

The LVD contactor is a bi-stable, magnetically latched contactor. This means that failure of power or removal of the SM36 from a live system will not cause the contactor to change state.




FIG. 5 System Internal View

6 COMMISSIONING

Use the following set of instructions as a guide, unless different procedures are recommended by local authorities.

Note: Refer to Appendix 1 to check important System Set-up parameters while commissioning.

Pre-check:

1. No more building work to be carried out in site to avoid concrete and plaster dust being ingested into rectifiers and systems.
2. System installation is completed.
3. Battery and load circuit breakers are turned off, and upstream AC has been turned off (i.e., system is completely de-powered).
4. Rectifier modules have been fitted into their shelf positions, and pulled forward enough to disconnect them from the system.

Note: Unless chassis DC isolation is specified when ordering, this system is supplied with the AC and DC earths connected. This system has DC Common in the Positive side of the circuit (+ve earth system or -48 VDC). Before connecting the Batteries or Rectifiers ensure that Earthing is correct for your application (24 VDC are normally wired for –ve earth system or +24 VDC).

5. Turn on AC upstream and check that voltages from phase to neutral are as expected.

Rectifier Start-up

1. Turn the upstream AC circuits on.
2. Fully insert first rectifier, wait for the rectifier to start and its power on LED to remain green.
3. Check the SM36 powers up, and indicates the system default float voltage (approx. 54V on its display). If the audible alarm activates, press any SM36 button to silence it.
4. If a different system float voltage has been specified, set this at this time using the procedure specified in the SM36 Manual (either from the front panel or connected computer).
5. Fully insert the rest of the rectifiers ensuring they power up with only their green “power on” LED illuminated.
6. Check that the load and battery currents on the SM36 are 0 amps (+/- 1 or 2 amps).
7. Check that all SM36 configuration settings are correct (as per customer specification) with respect to:
 - Voltage levels
 - Alarm settings
 - Alarm mappings to the volts-free relays
 (Refer to the SM36 manual for information on how to check these via the front panel or locally connected computer).

Battery Start-up

Note: It is preferable that battery circuit breaker connections should be made when the rectifiers are turned on and the system is “live”. This is because the system voltage and battery voltages will be similar, thus minimizing any arcing during connection. This also prevents high current arcing due to the charging of the rectifier output capacitors.

1. Power up only one rectifier initially (to limit any damage if any connections are incorrect).
2. Measure the voltage across each battery string at the terminals of the Compact System. Ensure that the reading from the DC Common bus to the Battery Live Terminals is -48V as per System specification.
3. Turn on battery circuit breaker measuring the battery voltage. Ensure that the voltage increases slightly to the system Float Voltage (typically the voltage will increase from 2 to 3V below float voltage. At this point the batteries will be drawing some current to bring them to a full state of charge.

Load Start-up

1. Ensure downstream load connections have been made and there are no loose/floating load cables.
2. Turn on load circuit breaker, ensuring that the downstream equipment is being powered up as expected.
3. Ensure the system float voltage on the SM36 is at the level previously noted.
4. Ensure the load current is at a level expected (could be zero if loads downstream have not been connected).

Note: Prior to leaving the system after it has been commissioned, ensure all AC, DC *and* battery circuits are off. If it is required that the system is to be left on (to power load equipment, ensure rectifiers are left in their powered up state, and batteries are in circuit. This will prevent anyone leaving the batteries only powering the load (in which case the batteries would go flat).

DC System Commissioning Check List

Note that the values in the following check-boxes are for a 48V nominal system, and are for example only. Values for a 24V system are proportionately lower.

This check-list can be altered and printed off for use as required.

DC SYSTEM COMMISSIONING CHECK-LIST				
Site Name:			Date:	
Tests Without Batteries Connected		Measured/ Setting	Results	
	Check Float Voltage	Meter:	V	✓ / ✗
	Check Load Current	Meter:	A	✓ / ✗
	Alarms:			
	<p>Voltage thresholds can either be checked using an external power supply, or by adjusting the SM36 float voltage 0.1V above (or below for the low voltage alarms). It is recommended to have the batteries disconnected.</p> <ol style="list-style-type: none"> 1. Adjust the supply/float voltage to 55.7V & observe the "High Float" alarm. 2. Adjust the supply/float voltage to 57.7V & observe the "High Load" alarm. 3. Adjust the supply/float voltage to 52.7V & observe the "Low Float" alarm. 4. Adjust the supply/float voltage to 46.9V & observe the "Low Load" alarm. 			
	High Load Volts (urgent)	57.6V	V	✓ / ✗
	High Float Volts (non-urgent)	55.6V	V	✓ / ✗
	Low Float Volts (non-urgent)	52.8V	V	✓ / ✗
	Low Load Volts (urgent)	47.0V	V	✓ / ✗
	<p>Depending on the test load available, it may be necessary to adjust the High Load Current alarm threshold down to suit. For example, with the 70A test load, adjust the High Load Current threshold (use SM36 Config. software, click on the "Alarms/(Levels)") to 60A. Then simply apply the 70A load and observe the alarm change state.</p> <p>Once the test is complete, be sure to rest the High Load Current to its previous value (or check with the customer for the correct value they require).</p>			
	High Load Current (urgent)		A	✓ / ✗
	<p>Temperature alarm tests are performed by heating up (using a heat gun or other source) and cooling down (using an aerosol can of freeze, or a tub of ice) the temperature sensors. Note that when the Battery Condition Monitor is used, there is one sensor per battery string. The SM36 uses the average of these temperatures as the "Battery Temperature". Therefore, all the sensors need to be heated / cooled at the same time.</p>			
	Battery Temperature High (urgent)		°C	✓ / ✗

	Battery Temperature Low (non-urgent)		°C	✓ / ✕
	Room Temperature High (non-urgent)		°C	✓ / ✕
	Room Temperature Low (non-urgent)		°C	✓ / ✕
	<p>When an AC Monitoring PCB is not fitted at system level (as in most cases), the AC Fail alarm is generated from the rectifiers. The rectifiers sense if AC is present, and extend an AC fail alarm to the SM36. Therefore, to test this alarm, simply turn off the rectifier AC breakers. To allow the monitor to continue to read alarms there must be DC present on the output of the system.</p> <p>As this causes the rectifier output to cease, a Rectifier Fail alarm is also generated. To generate the Urgent Rectifier Fail, turn off the required number to make this occur (Usually set to 1, but check via the SM36 Config software for the setting (under the "Rectifier Control" section of the "Power Module Control" tab)).</p>			
	AC Fail (urgent)		Urgent	✓ / ✕
	Rectifier Fail (non-urgent)		Non-urgent	✓ / ✕
	Urgent Rectifier Fail (urgent)		No. Modules:	✓ / ✕
	<p>To check Load MCB Open, connect a load, but with no load turned on. Then switch the breaker to it's off position and turn on some load (any amount will do). This will cause the alarm to occur as the load side to the circuit will be taken to system common voltage. Turn off the load, and then return the breaker to its ON position.</p>			
	Load MCB Open (urgent)			✓ / ✕
	<p>The battery circuit breakers use auxiliary contacts to detect tripping or whether they are turned off. This is because when a battery breaker is tripped, there may be very little voltage difference, making electronic fail detection problematic. Hence, if only one battery is connected, both breakers must be "on" to clear the Battery Breaker Fail alarm.</p> <p>To check Battery MCB open alarm, turn off the battery circuit breaker.</p>			
	Battery MCB Open (urgent)			✓ / ✕
	<p>To check the Surge Protection Failed alarm, simply pull the MOV out. This switches a micro-switch within the SPD unit. Once pulled, observe the alarm, and re-insert the MOV block and observe the alarm clear. (Only available when SPD is fitted in the system).</p>			
	MOV (SPD) Fail (urgent)			✓ / ✕
	<p>A Rectifier Off Normal alarm is generated with the rectifier enters a state that may degrade its performance (e.g., a single fan fail), or a state that is outside of normal operating conditions (e.g., high temperature, or current limit).</p> <p>You can observe an Off Normal alarm when the system is placed in current limit, or you may wish to stop a fan to generate the alarm. The best way to stop a fan is to use a small cable tie (non-metallic), and push it approximately 1cm through the rectifier grille.</p>			
	Rectifier Off Normal (e.g., fan failed) (non-urgent)			✓ / ✕

Tests with Batteries				
	<ul style="list-style-type: none"> Set V_i to equal battery voltage Connect battery/batteries Check the correct Battery Capacity (Ahrs) has been entered (SM36 Config., "Charge" tab). This is the total capacity, so for 100Ahr string, this should be 100. <p>Go to SM36 Config, "Control" tab. Set the Battery Charge Current Limit to "Enabled" (middle right of screen). Also check Battery Current Limit (BCL) is set to desired level (usually $0.25C_{10}$, (25%)). This means that for a single 100Ahr battery, the BCL will be 25A, or if two 100Ahr batteries are connected in parallel, the BCL will be 50A.</p> <ul style="list-style-type: none"> Go to SM36 Config. "Battery Monitoring" tab. "Tick" Logging Enabled. Set: <ul style="list-style-type: none"> Status Log Sampling Interval to 7 days (provides a "snapshot" of the battery state every 7 days) Discharge Log Sampling Interval to 1 minute Discharge Log Continuation Time to 5 minutes (this is the length of time logging continues for after AC power is returned) Connect load (but turn off). Set V_i to 54.0V. Turn on Battery Breaker/s 			
	Check Battery current is positive if charging			✓ / ✗
	For systems fitted with Battery Monitoring (BCM) cards: Go to SM36 Config., "Battery Monitoring" tab and "tick" start scanning. Check that the all the battery cell voltages are approximately the same, at about 2.25V (or 13.5V for 12V monoblocs). If any are out by a large amount, then check the BCM sense wiring is correct			
	Set load to required level (e.g., 50A), Initiate Battery Discharge Test (from SM36 Config., "Charge" tab, click "Battery Test Enabled")		Check operates	✓ / ✗
	Check Battery Current is negative (discharging)			✓ / ✗
	Check Battery Current	Meter:	A	✓ / ✗
	After several minutes or until the battery voltage has dropped below approx. 47V, "un-tick" (stop) Battery Test (from SM36 Config., "Charge" tab). During this time the Battery Condition Monitor (if fitted) will be logging every minute.			
	Battery Current Limit (BCL) Check that the battery recharge current is		BCL functions	

	Limited to the Battery Current Limit level (usually between 0.25C ₁₀ , (25%)) Note: as the BCL is based on fine voltage control of the system bus, the BCL make take one or two minutes to “settle”, i.e., you may observe a brief excursion of the battery recharge current beyond the BCL setting.		%	Yes/No
	Check Manual Equalise (if configured)			✓ / ✕
Temperature Compensation				
	Ensure Temperature Compensation Enabled			Yes/No
	Apply heat or cold to the Battery Temperature Sensor/s. Check the float voltage moves up or down as expected.			Yes/No
	If actual measurement is required, apply a known heat or cold to the sensor. Allow it to fully come to temperature, and record the amount of voltage movement.		Temp. °C Voltage offset: V OK?	Yes/No
Check Alarm Relay Contacts				
	To generate these alarms, refer to the procedures described earlier in the Commissioning Check-list. Spare relays will not be able to be tested unless an alarm is mapped to them. As these are tested in the factory, it is not essential to test them at time of commissioning.			
	Relay 1 (Monitor Fail) (pull out the RJ45 lead connecting the monitor to the system rectifier shelf – this simply de-powers the monitor)			✓ / ✕
	Relay 2 (Summary Non-urgent)			✓ / ✕
	Relay 3 (Summary Urgent)			✓ / ✕
	Relay 4 (Spare) For SM35/36 only			✓ / ✕
	Relay 5 (Spare) For SM35/36 only			✓ / ✕
	Relay 6 (Spare) For SM35/36 only			✓ / ✕

7 APPENDIX 1 – NEWMAR ESSENTIAL SYSTEM SET – UP PARAMETERS

The following items 1 through 5 are system settings that **MUST** be checked for **EACH** system installed, at the time of commissioning.

WARNING: Failure to correctly follow the procedures in items 1 to 5 below may at least cause incorrect system function, and at worst **ruin** your battery (**without** the ability to claim battery replacement under warranty).

PRIOR to making any changes to settings, ensure that you back up the Configuration settings that the SM36 is supplied with. To do this, go to the Setup page and click on the “Save Variable to File” button. The filename is saved with a “.SM3x” extension.

Note that the values in the following check-boxes are for a 48V nominal system, and are for example only. Values for a 24V system are proportionately lower.

1. Check/Set Float Voltage

Consult battery manufacturer’s data for proper setting.
The Float voltage is for 25°C reference temperature in Newmarsystems.
SM36 Config Page: [Power Module Control](#)

Rectifier Float Voltage Setpoint	<input type="text" value="54.00"/>	V	<input type="checkbox"/>
----------------------------------	------------------------------------	---	--------------------------

2. Set Battery Settings

Temperature Compensation
You **must** consult the battery manufacturer’s data to obtain the correct Slope setting.
SM36 Config Page: [Charge](#)

Temperature Compensation			
<input checked="" type="checkbox"/> Enabled			
Temperature Slope Compensation	<input type="text" value="-3.0"/>	mV/°C/Cell	
Temperature Min Control limit	<input type="text" value="0.0"/>	°C	
Temperature Max Control Limit	<input type="text" value="50.0"/>	°C	
Number of Cells	<input type="text" value="24"/>		

Done: ☐

If you choose **not** to enable Temperature Compensation, then set the Rectifier Float Voltage to that required by the battery manufacturer for the average long-term temperature you anticipate your system to operate at.

3. Battery Size

For the SM36 to set the correct Battery Current Limit current, it is essential that this is filled out correctly. These figures are also used for estimating the Battery Time Remaining during a discharge.

For Telecom applications, the 10 hour rate is usually the name-plate rating of the battery. However, once again, check the battery manufacturer’s data sheets as some manufacturers state the 20 hour rate (which is usually a little more “optimistic”).

The second rate is required specifically for the time-remaining algorithm. A 4 hour rate is usually a good one to use. This information is available from the battery manufacturer’s data sheet.

SM36 Config Page: Charge

Battery Capacity			
Capacity At	10	Hour Rate	100 Ahr
Capacity At	4	Hour Rate	73.6 Ahr
Discharge Time Remaining		---	Minutes
10 Hour Rate Capacity Remaining		100	%

Done: ☐

Note – you need to change both the 10 hour and 4 hour rates at the same time. The rates need to be reasonably accurate (in terms of the proportion of 4 hour to 10 hour rates), otherwise the SM36 may not accept the settings.

4. Battery Current Limit

The Battery Current Limit is set as a percentage of the 10 hour rate entered in step 3.

SM36 Config Page: Control

Battery Charge Current Limit	
<input checked="" type="checkbox"/> Enabled	
Battery Charge Current Limit	25 %

Done: ☐

Newmar recommends that you set this value at the highest rate possible to ensure the battery is recharged as fast as possible (this could be as high as 30%, depending on the manufacturer). However, especially in large systems, this may be more limited by the number of rectifiers available, rather than this particular setting. For telco settings, this is often set to 10% (or $0.1C_{10}$, so for a 100Ahr battery, the current limit is 10A). This is more typical of a design parameter than the need for the setting to be at this level. So a setting higher than this level should be considered to enable the fastest recharge possible. However, consult the battery manufacturer data to find the maximum value.

5. Low Voltage Disconnect Settings

SM36 Config Page: Alarms (Levels)

Low Voltage Disconnect Setpoint		
LVD1 Disconnect Setpoint	43.00	V
LVD1 Reconnect Setpoint	48.00	V
LVD2 Disconnect Setpoint	10.00	V
LVD2 Reconnect Setpoint	15.00	V
LVD3 Disconnect Setpoint	10.00	V
LVD3 Reconnect Setpoint	15.00	V

Done: ☐

This is usually a customer generated setting. Normally, the longer the discharge, the higher the end voltage. So, for a discharge of <1hr, this may be 1.75Vpc (42.0V for a “48V” battery), or for an 8 hour discharge, it may be 1.85Vpc (44.4V for a “48V” battery).

Note that if only one LVD is fitted, then the other thresholds (of LVD2 & LVD3) are normally set well outside of possible tripping voltages. Although not essential, and those LVDs will not be enabled anyway, it serves to avoid any confusion over which LVD signal is actually being used.

8 APPENDIX 2 – MAINTENANCE

As NEWMAR Power Systems are state of the art electronic systems, very little routine maintenance is required

System

During normal operation the cable entries to the MCB's may loosen over time due to movement in the cable strands.

To avoid damage to the MCB's and cable entries due to heat build-up and arching, it is recommended that the retaining torque is periodically checked at least annually.

MCB's should be maintained at a torque of 2Nm

All other connections should also be checked at this time.

Monitor

The monitor can give a good indication of the condition of the system. Alarm logs can show issues with the system and rectifiers and should be regularly checked.

As a minimum check ensure the float voltage and load current is as expected.

If the batteries are fully charged, check the battery current is zero or near to zero amps.

Rectifiers

During normal operation some dust will build-up on the front of the rectifiers. This should be kept to a minimum by regularly wiping the rectifiers to avoid accumulation within the rectifiers and blocking the airflow to the units. The positioning of the system and surroundings will determine the regularity of this requirement.

In extremely dusty positions it is recommended that the units are removed and cleaned with compressed air to prevent airflow blockages.

Batteries

Battery maintenance will depend on the individual manufacturer's specification, please contact the battery supplier for recommendations.

9 APPENDIX 3 – AC INPUT TRANSIENT PROTECTION





Fig 6.0 Illustrates the surge protection installation principles.

The **Type 1** surge arrester, fitted in the installation's main incoming electrical switchboard, is capable of deviating the energy of a direct lightning strike. This is the first stage of the electrical network's protection. It is important that upstream Type 1 protection is provided on site.

10/350 wave as shown below is the current waveform which passes through equipment when subjected to an overvoltage due to a direct lightning strike.



A **Type 2** surge arrester should be used in coordination with the incoming surge arrester. This is the second stage of protection. Type 2 Surge arrester is designed to run-off energy caused by an overvoltage comparable to that of an indirect lightning strike or an operating overvoltage.

Some of the Newmar Power System models are provided with Type 2 Surge Protection Devices (SPDs) (as defined by IEC 61643-11). These devices are rated for repeated strikes of 20kA (8/20μs waveform as shown above), and single shot protection of 40kA.


Note: Newmar Rectifiers are compliant with EN6100-4-5, Level 4 without any external/upstream surge suppression. To maintain a coordinated approach to surge suppression, Type 2 SPD should be installed upstream if not fitted in the system.

To ensure correct operation of the SPDs, at least 10m of AC feeder cable is fitted between the Type 1 and Type 2 protection. If the distance is less than 10m, then loop the cable until at least 10m of cable is used. This ensures correct de-coupling of the SPD devices.


Notes on AC cable installation and SPDs

The following precautions must be adhered to when installing AC cabling.

1. Avoid running input and output cables from AC Surge Protection Devices together:




2. Avoid "Tee'd" Connections:



10 APPENDIX 4 – RECTIFIER INPUT FUSE CURVES

* The curves are average value, for reference only *



APPENDIX 5 – INSTALLATION OF AC INPUT COVER




FIG. A




FIG. B

1. Fig. A and Fig. B shows the bottom edge of AC cover, which clips on the Din rail.
2. To remove the AC cover, lift the cover up as shown by the arrows pointing up in Fig. B
3. Once the upper end is released from the top of Din rail, pull the cover out as shown by the arrows pointing out in Fig B.
4. To put the cover back on the AC input terminals, clip the bottom of the AC cover on the Din rail as shown in Fig. B.
5. Once the cover is clipped on the Din rail, push the upper end of the cover under the top lid of the system. Make sure the AC cover is sitting correctly on the Din rail.

12 APPENDIX 6 – TROUBLESHOOTING

A) Resetting Passwords

- 1) Expert password lost
 - Uninstall SM3x Configuration Utility from computer
 - Reinstall SM3x Configuration Utility on computer
- 2) Reset Network Password
 - In the left hand column of the software, right click and a box will give login options. Log- on option is Expert and will request the password (“expert”).
 - Then open the Network tab and click the “Reset Web Passwords” box.
 - a. Enter new Web Administrator Username
 - i. Click W icon next to field to save information
 - b. Enter new Web Administrator Password
 - i. Click W icon next to field to save information
 - c. Enter new Web User Level Username
 - i. Click W icon next to field to save information
 - d. Enter new Web User Level Password
 - i. Click W icon next to field to save information

B) Measuring voltage on output: Load circuit breakers are off but I’m measuring DC voltage on the output terminal block.

- This is normal. The load breakers are monitored electronically via a diode to a digital input on the SM36. This is a high impedance residual voltage and does not present a hazard to the user – see “Circuit Breaker Fail Monitoring” under section 4.4
Alarm/Ancillary

C) AC Meter Shows Incorrect Voltage

- Meter requires greater than a 2 amp load to measure correctly

D) SM36 Module does not stay in place

- On the left side of the module is a small ballscrew that can be adjusted to maintain proper holding fording of the SM3x inside the chaise.

E) Rectifiers come out of shelf

- Verify that the rectifier is fully inserted and using a small flathead screwdriver the green locking tab on the right side is pressed down.


13 APPENDIX 7 – Field Replacement of Load Circuit Breakers

Instructions for field installation of load circuit breaker. To be performed by qualified electrical personnel only.

1. Remove the A.C. input and turn both battery breakers off. (If the unit is still powered on a live bus will be exposed creating a possible shock hazard).
2. Remove the top of the unit (there will be 1 screw in each corner and two screws located in the front center of the unit).
3. Remove the bottom circuit breaker toggle guard.
4. The output terminal block wires are labeled according to their position, locate the wire corresponding to the breaker position you are installing and connect it to the bottom contact of the circuit breaker.
5. Attach any hot wire from the bus to the top contact of the circuit breaker.
6. Insert a screw into the hole exposed by removing the bottom toggle guard and screw the breaker in place.
7. Re-install the toggle guard and top of the unit and reapply power.

Note: It is normal to measure output voltage on a Centurion II load circuit breaker when its toggle handle is in the OFF position. The Centurion II circuit breaker alarm circuit produces a very low current, high impedance signal that can be detected using a high impedance digital multi-meter (DMM). This is normal and does not present a hazard to the user.

14 Appendix 8 – System Wiring Diagrams



Centurion II Power System, -48 or -60 (+Ve earth)

