

# PE Series

# Annunciator Panel

## Installation/Operation Manual

### Model: AP-8000B



Section	Page
Safety Information.....	1
1.0. Circuit Board Illustration.....	2
2.0. General Information.....	3
3.0. Installation and Wiring.....	4
4.0. Programming and RS-485 Features.....	6
5.0. Summary Alarm Option (Auto Dialer)....	7
6.0. RS-485 & Master Remote Operation...	7
7.0. Battery Back-up Option (6 Volt DC).....	8
8.0. Specifications.....	8
9.0. Regulatory Information.....	9
10.0. Troubleshooting.....	9
11.0. Limited Warranty.....	9
12.0. AP-8000B Power Source Options.....	10
Wiring Diagram.....	11

**M-AP8000B**  
**As of 110320**

## Safety Information

FOR COMMERCIAL USE ONLY



### CAUTION

Up to 60 Volts DC may be present on the terminals.  
**DO NOT SHORT ACROSS THE POWER SUPPLY TERMINALS**


- Keep fingers and all metal objects from power terminals and wires.
- Use insulated hand tools.
- Recommended: When this device is connected to an alarm panel, place the alarm system in "Test Mode" prior to servicing.

**CAUTION:** Disconnect power before attempting to service or repair this product.

This device must be installed in accordance with all applicable electrical and building codes.

**NOTICE:** No user-serviceable parts inside. Refer all repairs to qualified service personnel.

## 1.0 Circuit Board Illustration



## 2.0 General Information

### Features:

- 2.1. The AP-8000B is a Microprocessor controlled fire alarm annunciator panel for use with In-building 2-Way Emergency Radio Communication Enhancement Systems (ERCES) required by the National Fire Protection Agency (NFPA 1221). It monitors the alarms of the Bi-Directional Amplifier (BDA) and Battery Back-up Unit (BBU) and provides visual and audible alarms as well as communicates these alarms to the fire control panel via up to eight sets of form C alarm contacts.
- 2.2. Alarm inputs: 8 alarm input capacity to accommodate new UL2524 alarm point requirements. Five inputs are standard/labeled on face of panel and the panel can accept an additional three alarms as required by new UL Standard 2524 (additional labels included).
- 2.3. Alarm Input Wiring Supervision: continuously monitors alarm input wiring for faults, selectable for either Normally Open or Normally Closed alarm contact monitoring. Immediately flashes the alarm LED that has faulted and produces an audible alarm (beeping) whenever an alarm input wire becomes broken or shorted. End of line resistors (2.2 k Ohm 1%, 1W resistors provided) are installed at the BBU & BDA alarm contacts to enable this feature. Enabling of NO or NC monitoring is done by simple DIP switch placement.
- 2.4. One model, operates on 9-60V DC input
- 2.5. Easy set-up and installation:
  - All programming done via 8 DIP switches - no trim pots to turn taking out guess work if the pot is set properly.
  - Alarm panel end of line resistor landings provided for alarm panel connection.
  - Cable feed thru locations: Drill locations include bottom or sides. In addition, space is provided on the lower back panel of enclosure for rear cable/conduit access. One 1/2" and one 3/4" liquid tight cord grips included.
  - Three jumpers provided to allow disabling of alarms that are not in use- no zero ohm resistors required.
- 2.6. Master/Remote Operation: Up to 15 additional AP-8000B's can be connected in a daisy chain fashion using a standard Cat 5 cable. A selector switch allows the Master's power source to be provided downstream to power the remotes via POE, eliminating the need to run separate power feeds to each Remote. Exception: If using 6 volt battery back-up at Remotes, a separate input power is required at each Remote.
- 2.7. Additional optional alarms:
  - Loss of 5 volt DC internal power Alarm
  - Alarm input # 8 can be programmed to provide a summary alarm for activating an auto dialer.
- 2.8. Enclosure: UL Listed NEMA 4 box ensures no water penetration during an emergency when used with liquid tight cord grips or conduit fittings.
- 2.9. Built in 6 volt battery charger: Add optional 6 volt battery (P/N: 591-0126-0) for internal battery back-up. Useful for 120V AC systems where an AC adapter is used to power the annunciator panel or to meet AHJ requirements for separate, internal annunciator battery back-up. See **Section 7** for more information.
- 2.10. Security: AP-8000B Features a 1/4 turn door latch which can be changed easily and quickly to either a quarter-turn keylock, or padlock lock, when required to deter unauthorized access.

### 2.2 Materials Provided:

- 1 ea. AP-8000B Annunciator Panel
- 1 ea. Installation/Operation Manual
- 1 set of UL 2524 Alarm Labels:
  - "Active RF Device Failure"
  - "Active Component Failure"
  - "Donor Antenna Failure"
- 4 ea. #10 x 3/4" Philip Head Mounting Screws
- 3 ea. Small Programming Jumpers, installed in alarm input positions #6, #7, #8
- 1 ea. In-line Fuse Holder
- 1 ea. 2 Amp Input Power Fuse
- 1 ea. 1/2" NPT Cord Grip (IP68)
- 1 ea. 3/4" NPT Cord Grip (IP68)
- 8 ea. 2.2 K ohm, 1%, 1 Watt end-of-line (EOL) termination resistors
- 1 ea. 11" x 17" Mounting Template
- 1 ea. Two position pluggable terminal block for 6 volt battery (option)
- 2 ea. Female Fast-on (0.187") crimp connector for 22 - 18 AWG for optional 6 volt battery (P/N: 591-0126-0)
- 2 ea. #6 crimp ring lug for 22 - 18 AWG for making GND/RETURN screw wire connection

The Annunciator provides one "Form-C" relay output for up to (8) eight alarm conditions to the building's main fire alarm panel control panel (FACP) or other device. Typical UL-2524 installations require at least the following alarm conditions to be annunciated:

1. Loss of AC power
2. Low battery, indicating the battery has discharged by 70%
3. Charger failure
4. BDA Failure
5. Antenna Failure
6. Active RF Device Failure\*
7. Active Component Failure\*
8. Donor Antenna Failure\*

\* Labels included

### 3.0 Installation & Wiring

#### 3.1 Wall-Mount Installation:

1. One 1/2" NPT and one 3/4" NPT liquid tight cord grips are provided. Choose a location to drill the appropriate size hole (1/2" NPT = 7/8" and 3/4" = 1-1/8"). Recommended cord grip hole drill ocations are the two sides, bottom and rear in the opening provided at the bottom of the circuit board. **CAUTION:** Remove drill shavings before powering AP-8000B or severe damage can occur.
2. The AP-8000B is designed to be wall mounted. Select a suitable location in accordance with any approved building plans or as specified by the Authority Having Jurisdiction (AHJ).
3. Affix the enclosure to the wall using the supplied mounting screws.
4. Flush Mounting: If mounting inside a wall space, ensure adequate space to all opening and closing of the door.

If required, alternative mounting arrangements may be used but avoid drilling new holes in the front cover door.

#### 3.2 Wiring

**Power Source Wiring Options:** (9-60V DC Input, <100 mA)

Reverse Polarity protection note: If the DC power source is connected reverse polarity it will simply blow the 2 amp slow blow fuse to the left of the input power terminal block and protect the annunciator. Replace with Littlefuse #.33002 MXP or equivalent.

The DC input terminal block is located in the lower left hand side corner of circuit board and will accept 12 to 22 AWG wire size. Maximum current draw is 100 milliamps.

**Option #1 BBU DC Power:** Connect annunciator DC power input terminals to BBU DC output. Use provided inline fuse holder & 2 Amp fuse wired on the + VDC power at the BBU output terminal blocks. See **Wiring Diagrams on Page 10, Figures 8 and 9.**


**Option #2 120 VAC Power Source:** Use a 120V AC to 12V DC AC wall adapter, 1 amp size recommended. **Note:** Battery back up is recommended whenever powering the annunciator panel from 120V AC power. See battery 6 volt battery back-up **Section 7** for details.

#### 3.3 Alarm Input Wiring from BBU & BDA General Info: (Refer to Figure 2)

- Connect alarm input wiring to the 8-position green terminal block located on left hand side of circuit board which accepts wire sizes 16 to 24 AWG.
- Strip wire back approximately 3/8", press down on orange lever with a small screwdriver to open the spring loaded opening, and insert wire end into top opening of terminal block and release the orange lever. Verify connection by tugging on wire and ensuring wire is secure.
- Wiring tip: Jumper the 'C' (COMMON) Alarm contacts at the BBU and BDA in parallel and run a single Common wire to the annunciator panel GND/Return screw terminal.


**CAUTION:** Do not simultaneously apply power to both the main Input Power Connector and the above terminals. Doing so may damage the annunciator or any external equipment connected to it.

**Figure 2: 8 Position + Ground/Return Screw Terminal Block**



POSITION #	FUNCTION
1	Alarm Input #1/AC Power Fail
2	Alarm Input #2/Low Battery
3	Alarm Input #3/Charger Fail
4	Alarm Input #4/BDA Fail
5	Alarm Input #5/Antenna Fail
6	Alarm Input #6
7	Alarm Input #7
8	Alarm Input #8
Screw (#6 - 32)	GND/Return

**Figure 1: AC Power Input Terminal Block**





**3.4 Alarm Contact Type Setting:** The annunciator monitors up to 8 alarm contacts from the BBU and BDA. The AP-8000B can be set to monitor all contacts in either Normally Open or Normally Closed position. Set the Function DIP switch #2 (see **Figure 3**) as follows:

OFF = Contact closure initiates the alarm so wire to BBU/BDA NO Normally Open contacts *when powered and no alarms* (Factory Default)

ON = Contact open initiates the alarm so wire to BBU/BDA NC Normally Closed contacts *when powered and no alarms*

See **Section 4.0** for more information on the Function Dip Switch

**3.5 Alarm Disable Jumpers:** Alarms #6 (Active RF Device Failure), #7 (Active Component Failure) & #8 (Donor Antenna Failure). If not wiring these three alarms leave the three small jumpers installed at the factory. Remove them if you intend to connect alarms #6 thru #8.

#### End of Line Resistors (EOL)

In order to supervise input wiring for faults, an end of line resistor (2.2K ohm, 1 watt, 1%), resistor (included), must be installed at the BBU and BDA for each alarm contact.


End of Line (EOL) Resistor Wiring for Non-UL PE (BBU) models where resistors connect directly to the BDS-DIN-UPS XX-XX charging unit. BDS alarm contacts state shown on front panel are shown with no power or battery connected to the BDS-DIN UPS. As such Normally Open is Normally Closed & Normally Closed is Normally Open when BBU is powered up and has no alarms.

**Note:** Wiring diagrams for EOL resistor wiring for Non-UL PE (BBU) follows. See **Section 12 on page 10** for wiring diagrams for EOL resistor wiring for Newmar UL PE (BBU).


**Figure 4A: End of Line Resistor Installation**

#### Non-UL Newmar PE (BBU) Resistor Installation for Monitoring Normally Open Contacts

**Example Shown:  
Model BDS-DIN-UPS 48-10**




**Note:** BDS alarm contacts state shown on front panel are shown with no power or battery connected to the BDS-DIN UPS. As such Normally Open is Normally Closed and Normally Closed is Normally Open when the BBU is powered and has no alarms.



**Notes:**  
1) EOL Resistor: 2.2kΩ, 1W, 1%

Charger Fail  
GND/ Return  
To the Annunciator Panel


**Figure 3: Function DIP Switch**



**Figure 4B: End of Line Resistor Installation**

**Non-UL Newmar PE (BBU) Resistor Installation for Monitoring Normally Closed Contacts**

**Example Shown:  
Model BDS-DIN-UPS 48-10**



### 3.6 SILENCE Button:

- Press and hold for 2 seconds to activate silence.
- Pressing SILENCE on any annunciator (whether Master or Remote) silences all annunciators for 24 hours.

After 24 hours, the beeper activates again (if there is no change in alarm status), in accordance with UL-2524. If the alarm status changes while the 24-hour silence is in effect (i.e., a new alarm arrives, or an old alarm condition recovers), the 24-hour silence timer is reset and the beeper sounds. If the SILENCE button is pressed on any annunciator (whether Master or Remote) while silence is already in effect, the button press is ignored. (i.e., additional time is not added.)

### 3.7 Connection to the Building's Main Fire Alarm Panel: *(This step is optional.)*

The AP-8000B provides (8) Form-C relay outputs that may be connected to the building's fire alarm control panel (FACP). A corresponding Red LED will illuminate when the alarm is activated. A corresponding Red LED will illuminate when the alarm is activated. Confirm with your local building inspector/authority having jurisdiction ("AHJ") whether such connections are permissible in your area.

Each Form-C alarm output relay has a separate wiring terminal. These terminals are located along the right-hand side of the circuit board with "Alarm 1" at the top, and "Alarm 8" at the bottom.

The alarm relay terminals accept wire sizes 18 - 22 AWG.

**End Of Line Resistors:** If desired, an in-series "End of Line" supervision resistor may be installed on the screw terminals adjacent to the relays. Any EOL resistors placed here will be "in-series" with the Common terminal of the Form-C relay. If these EOL terminals are not used, they must be shorted across, so that the Common terminal of the relay is presented to the FACP wiring block

## 4.0 Programming and RS-485 Features

### 4.1 Function Switch: 4-Position DIP switch (left of processor):

Switch-1 = Beeper OFF/ON (Off = No beeper, On = Beeper will sound on alarms)

Switch-2 = Relay contact selection (ON=Normally Closed/Contact Open activates alarm, OFF=Normally Open/Contact Closure activates alarm)

Switch-3 = Normal or summary alarm (OFF = Normal Donor Antenna Failure Alarm operation, ON = Summary Alarm or Auto-Dialer Activation). See **Section 5** 'Summary Alarm Option (Auto-Dialer)' for more information

Switch-4 = Selects Master/Remote (Off = Master, On = Remote)

#### 4.2 Address Switch (see Figure 5): 4-Position DIP switch (right side of processor):

This sets the annunciator address in binary. (0 - 15). Set a unique address for each annunciator panel. Example:

Remote #1: ON/ON/OFF/OFF

Remote #2: ON/ON/ON/OFF

Remote #3: ON/ON/ON/ON

Remote #4: OFF/ON/ON/ON

### 5.0 Summary Alarm Option (Auto Dialer)

The AP-8000B can be set to activate relay #8 whenever any one or more of the alarm inputs (#1 - #7) are activated. This summary alarm can be used to activate an Auto Dialer for example.

To set relay #8 for summary alarm:

1. Disconnect power from AP-8000B
2. Open the door on the front of the AP-8000B
3. Identify DIP switch to the left of the main microprocessor
4. Set DIP switch #3 in the **Figure 6**
5. Re-connect power to the AP-8000B
6. Test, attach a continuity checker across the NO and COM terminals of relay #8 and activate any alarm (example: turn BDA Battery back-up (BBU) power battery breaker in the OFF position momentarily). Confirm relay #8 activates.

Figure 5: Address DIP Switch





Figure 6: Function DIP Switch



### 6.0 Master/Remote Wiring & Operation & RS-485

#### 6.1 Connect Wiring:

Up to 16 AP-8000B's can be connected in a Master/remote configuration. First set the Function DIP switch #4 for OFF=Master or ON=Remote. Next set a unique address for each unit on the Addressing switch (right side of microprocessor), reference **Section 4.2**.

Use a standard Cat. 5 cable to daisy chain master to remotes using the two RJ-45 jacks on each AP-8000B.

To set up a Master/Remote system, a selector switch allows the Master's power source to be provided downstream to power the remotes via POE, eliminating the need to run separate power feeds to each Remote. Example: Install one AP-8000B in the building entry area/lobby and one near the BDA & BBU or on a separate floor. Place the Remote Power switch in the up position.

#### 6.2 RS-485 Pinout:

- Pin -1: RS485A
- Pin -2: RS485B
- Pin -3: Ground
- Pin -4: PoE+ (Not Used)
- Pin -5: PoE+ (Not Used)
- Pin -6: Ground
- Pin -7: PoE- (Not Used)
- Pin -8: PoE- (Not Used)

#### 6.3 RS-485 LED Indicators:

- LED -10: Illuminates when the annunciator panel is transmitting over the RS-485 Serial Link.
- LED -11: Illuminates when the annunciator panel is receiving serial data from a remote annunciator.

#### 6.4 SL1 Termination:

- SL1 is the termination resistor for the RS-485 Serial Communication Bus.
- With the jumper placed over the left and center pins, the termination resistor is in-circuit. This is for "Master Only" configurations.
- With the jumper placed over the center and right pins, the termination resistor is out-of-circuit. This is used for Master and Remote configurations.



## 7.0 Battery Back-up Option (6 Volt DC):

If powering the AP-8000B from a 110V AC BBU 110V AC output or a 110V AC outlet we recommend installing the 6 volt battery back-up option, see **Figure 7**.

### 7.1 Materials Required:

- 1 x 6 volt, 1.2 AH sealed valve regulated lead acid battery with F2 terminals (.187"). Newmar p/n 591-0126-0.
- 1 x Two position ckt. board mating connector -provided
- 2 x .187" Female Fast-on crimp lugs- provided
- 2 x 18 to 22 AWG insulated wires, red & black, approximately 10" length. Installer supplied.

### 7.2 Wiring:

1. Cut two pieces of 18 to 22 AWG wire size, red & black recommended approximately 10" in length. Strip both ends of each wire approximately 1/4" and crimp one each 22-18 AWG .187" crimp female fast-on provided with AP-8000B on to the end of each wire.
2. Insert the other ends of stripped wires to the two position green pluggable terminal block provided with the AP-8000B. Be careful to ensure polarity is correct - see **Figure 7**. Positive/red wire should be on the left side when connector is mated to the circuit board connector. If battery is connected to the AP-8000B reverse polarity the ATC-1, 1 Amp fuse will blow and protect the circuit.
3. Connect the red wire w/female fast-on on to the battery positive (+) terminal. Connect the black wire w/female fast-on on to the battery negative (-) terminal.
4. Place the 6 volt 1.2 AH battery on the inside bottom of the AP-8000B enclosure and connect the green two position connector on to the mating connector on circuit board labeled 'Battery 6 V'. The AP-8000B should power up.
5. Connect a source of DC power to the 'Input Power 9 - 60V DC' terminal block and energize this power source. Measure voltage across the 6 volt battery and verify approximately 6.8V DC.
6. Verify battery back-up by disconnecting input power and verify AP-8000B remains powered and there's no interruption of operation. Reconnect input power.

**7.3 Power Failure Alarm Contact:** See **Figure 7** for location. Two position plug-able terminal block. Normally Closed when power to Annunciator is ok, opens upon loss of power. Accepts wire sizes: 14 - 22 AWG.

## 8.0 Specifications

Subject to Change without Notice

### General:

- Microprocessor controlled
- QTY-(8) Form-C, UL-Listed, Small Signal Relays
- "Heartbeat" indicator
- Front panel "Press-to-Test" button
- Easily adapted to fit nearly any situation
- RS-485 Serial Communication for Master/Remote Annunciator panel operation. Master and up to 15 remotes.
- Audible alarm (silenceable: 24 hours)


### Cabinet:

- Shipping weight: 8 Lbs.
- Dimensions (assembled): 10" H x 8" W x 4" D
- Environmental Rating: NEMA-4
- Closure: 1/4 Turn Twist-Lock
- Color: Red, Color# RAL-3001)
- Form-C, UL-Listed Small Signal Relay
- 2-Amp DC Rating (Resistive)

### Electrical:

- 9 - 60V DC
- Input Current Draw: <100mA max.
- Max Power: 4.5 Watts
- Relay switching current: 2-Amp DC (resistive)
- Optional battery: 6 volt, 1.2 amp-hour with 0.187" fast-on terminals (24 hour back-up time)

**Figure 7: Battery Back-up**



## 9.0 Regulatory Information

**California Prop-65 Warning Notice:** This product contains lead, a chemical known to the State of California to cause cancer, birth defects or other reproductive harm. Wash hands after handling lead products.



**Recycling Notice:** Please help protect the environment. We encourage all purchasers to recycle their lead-acid batteries. For the recycling location nearest you, please visit [www.call2recycle.org/](http://www.call2recycle.org/)

**FCC Part-15:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



## 10.0 Troubleshooting

This Universal Annunciator is designed and engineered to provide years of service in unattended commercial installations. With the exception of a single internal 2 amp ceramic fuse, there are no user serviceable parts inside.

In the event the annunciator fails to function properly, there are a few basic system checks that can be performed in the field:

- 1) Verify power LED located to the right of the Input Fuse is illuminating. If not illuminating, check 2 Amp input fuse. If fuse is ok, unplug the battery (if one is installed), and check the voltage at the green battery terminal. It should be 6.95 volts (+/- 0.15).
- 2) Check for the green, blinking "Heartbeat" LED light located at the upper left portion of the circuit board. This green LED blinks under microprocessor control. If the LED is blinking, it means the microprocessor is running and operating normally. If the Heartbeat LED is not illuminated, or is blinking erratically, there may be a problem with the power supplied to the device.
- 3) Verify that all wiring connections to all terminals are clean and tight, and that the wiring is fully under the terminal screws.

If the above system checks do not resolve the problem, please contact our Technical Support staff for further assistance.

## 11.0 Limited Warranty

Newmar warrants that the AP-8000B PE Series Annunciator Panel to be free from defects in material and workmanship for two years from date of purchase. If a problem with your AP-8000B or if you have any questions about the installation and proper operation of the unit, please contact NEWMAR's Technical Services Department:

Phone: 714-751-0488 - From the hours of 8:00 a.m. to 5:00 p.m. weekdays, P.S.T.;

Fax: 714-896-9679

E-mail: [techservice@newmarpower.com](mailto:techservice@newmarpower.com)

## 12.0 AP-8000B Power Source Options

Figure 8: Newmar UL Series PE Power Output (All DC Models)

### BBU DC Output






Figure 9: Newmar Non-UL Series PE Power Output


### BDS-DIN-UPS 12-10



### BDS-DIN-UPS 24-10



### BDS-DIN-UPS 48-10




## Annunciator Panel to Newmar UL PE Series BBU Wiring Diagram: 48V Example

### AP-8000B Alarm Inputs:

1. AC Fail
2. Low Battery/ Disconnect
3. Charger Fail
4. BDA Fail
5. Antenna Fail
6. Active RF Device Fail
7. Active Component Fail
8. Donor Antenna Fail

### AP-8000B Annunciator Panel



### \*Notes:

- 1) BDS unit factory wired for 120 VAC Input
- 2) Install 2 amp fuse, included with AP-8000
- 3) If PE System is **NOT** UL listed, attach AP-8000 power wiring directly to BDS Output

**Wiring Diagram:** AP-8000B Annunciator Panel

**Revision:** B

**Drawn By:** R. Wirtz