



Notes:  
1) BDS unit factory wired for 115 VAC Input  
see BDS-DIN UPS manual for 220VAC wiring.

**Wiring Diagram:** PE-110VAC-100W-100AH/24VDC  
**Date:** 27 FEB 17  
**Drawn By:** K. Henderson